



MAXURETHANE®

INJECTION -LV CLEANER

CLEANER AGENT FOR MAXURETHANE® INJECTION -LV POLYURETHANE INJECTION RESIN

DESCRIPTION

MAXURETHANE® INJECTION -LV CLEANER is a special agent for flushing and cleaning of **DRIZORO®** injection resins formulated with low viscosity polyurethane-based resins.

APPLICATION FIELDS

- General cleaning up and conditioning of tools, mixing equipment, hoses and injection pumps of **MAXURETHANE INJECTION® -LV**.

APPLICATION INSTRUCTIONS

All tools, mixing equipment and injection pump should be cleaned with **MAXURETHANE® INJECTION -LV CLEANER** immediately after use or if works are interrupted for a long period, i.e. more than 20 minutes. Do not leave resins in the pump for an extended time. A standard cleaning procedure is:

- Purge the equipment of the injection resins used.
- Do an initial flush with the cleaner and discard of the liquid.
- After purging the majority of resin, use and circulate **MAXURETHANE® INJECTION -LV CLEANER** through pump for at least 5 minutes at a high pressure and re-circulate. Use enough cleaner.
- Clean the pump and hoses thoroughly and frequently.

CONSUMPTION

Depending on use. Amount of liquid is determined by the pump size. Thus, the larger the pump, the hoses and its capacity the more quantity of cleaner agent is needed.

IMPORTANT INDICATIONS

- Polyurethane-based injection resins are water-reactive. Do not use water with the injection pump.
- Use only with adequate ventilation.
- When using, keep away from heat, flame and sources of ignition.
- Do not add solvents, or any other compounds to **MAXURETHANE® INJECTION -LV CLEANER**.
- For further information and other uses not specified in this Technical Bulletin consult our Technical Department.

PACKAGING

MAXURETHANE® INJECTION -LV CLEANER is supplied in 11 kg metallic drums.

STORAGE

Twelve months in its original unopened containers in a dry and covered place, with temperatures between 5 °C and 30 °C. Store in a ventilated area and protect against humidity, direct sunlight and frost.

SAFETY AND HEALTH

Do not work without the protection of rubber gloves and safety goggles. In case of eye contact, rinse immediately with clean

water but do not rub. In case of skin contact, wash with abundant water and soap. If irritation persists, seek medical assistance. If ingested, seek immediate medical assistance. Do not induce vomiting.

Observe the usual precautions necessary for the use and applications of this type of

products. Use in ventilated areas. Keep out of the reach of children.

For further information, Safety Data Sheet for **MAXURETHANE® INJECTION -LV CLEANER** is available by request.

Disposal of the product and its empty packaging must be made by the final user and according to official regulations.

TECHNICAL DATA

Characteristics of the product	
Appearance	Low viscosity liquid
Colour	Colourless
Density (g/cm ³)	0,98 ± 0,05
Solvent content (%)	0
Flash point (°C)	Non-flammable

GUARANTEE

The information contained in this leaflet is based on our experience and technical knowledge, obtained through laboratory testing and from bibliographic material. **DRIZORO®, S.A.** reserves the right to introduce changes without prior notice. Any use of this data beyond the purposes expressly specified in the leaflet will not be the Company's responsibility unless authorised by us. We shall not accept responsibility exceeding the value of the purchased product. The data shown on consumptions, measurement and yields are for guidance only and based on our experience. These data are subject to variation due to the specific atmospheric and jobsite conditions so reasonable variations from the data may be experienced. In order to know the real data, a test on the jobsite must be done, and it will be carried out under the client responsibility. We shall not accept responsibility exceeding the value of the purchased product. For any other doubt, consult our Technical Department. This version of bulletin replaces the previous one.



DRIZORO, S.A.

C/ Primavera 50-52 Parque Industrial Las Monjas
28850 TORREJÓN DE ARDOZ – MADRID (SPAIN)
Tel. 91 676 66 76 - 91 677 61 75 Fax. 91 675 78 13
e-mail: info@drizoro.com Web site: drizoro.com

ISO 9001
ISO 14001

BUREAU VERITAS
Certification

n° 6003176 / 6003176-MA

